


BIPOSTO- TENOR  
RM-BTABS

| Exploded View ID | RMI PART NUMBER | DESCRIPTION                                        |
|------------------|-----------------|----------------------------------------------------|
| AB1              | RM-AB1          | Bolt and washers                                   |
| ABA              | RM-ABA          | Articulating arm for ABS (Part of RM-ABS-ARM)      |
| ABAL             | RM-ABAL         | Left Rotational axle for ABS (Part of RM-ABS-ARM)  |
| ABAR             | RM-ABAR         | Right Rotational axle for ABS (Part of RM-ABS-ARM) |
| ABAL, ABAR, ABA  | RM-ABS-ARM      | Articulating Arm w/ Right and Left Axels for ABS   |
| ABAB             | RM-ABAB         | Join bolt for rotational axle                      |
| ABHB             | RM-ABHB         | Bolt, nut, and washers                             |
| ABM              | RM-ABM          | Backsaver for ABS                                  |
| ABS              | RM-ABS          | Adjustable back support plate w/foam               |
| ABSB             | RM-ABSB         | Backsaver screws (Pair)                            |
| ABSL             | RM-ABSL         | Left Shoulder for ABS w/foam                       |
| ABSR             | RM-ABSR         | Right Shoulder for ABS w/foam                      |
| ABT              | RM-ABT          | 3/4 Tbolt with pin & spacer                        |
| ABW              | RM-ABW          | Rubber washer for ABS                              |
| MPBP             | RM-MPBP         | Belly plate with foam -MonoPst                     |
| MPBPF            | RM-MPBPF        | Monoposto Belly Plate Foam                         |
| CH2              | RM-CH2          | N/A                                                |
| 2BCH             | RM-2BCH         | N/A                                                |
| 2BCH7MMT         | RM-2BCH7MMT     | Keybolts w/2wshrs/Hinge bridge                     |
| 2BCHTN           | RM-2BCHTN       | Lineal nut for double bolt hinge                   |

BIPOSTO- TENOR  
RM-BTABS


ABS  
ABAR  
ABT  
ABAB  
ABHB  
ABM  
ABAL  
AB1  
ABW  
7  
15ST  
20  
14  
CH2  
MPBPF  
MPBP  
LHTR  
LHTR  
35  
31  
32  
36  
32T  
37S  
38  
RM-BTABS

ABSR  
ABSB  
UHTL  
UHTR  
2BCHTN  
2BCH  
2BCH7MMT

RANDALL MAY INT'L

| Exploded View ID | RMI PART NUMBER | DESCRIPTION                   |
|------------------|-----------------|-------------------------------|
| LHTL             | RM-LHTL         | N/A                           |
| LHTR             | RM-LHTR         | N/A                           |
| UHTL             | RM-UHTL         | N/A                           |
| UHTR             | RM-UHTR         | N/A                           |
| 7                | RM-AT7          | Shoulder foam RM-MS (Pair)    |
| 14               | RM-MS14         | screw and washers ea          |
| 15               | RM-AT15S        | Shoulder clamp for snr/tnr    |
| 20DC             | RM-TROD6165     | Drum Key bolt and wshr 4 dual |
| 20               | RM-TROD627      | Drum Key Bolt and Wshr M6X27  |
| 31               | RM-BT31         | 1/4-20 x 3/8 set screw        |
| 32               | RM-BT32T        | Biposto saddle tube w/caps    |
| 35               | RM-M35          | 1-1/2 X 3-3/4 domed MAY label |
| 36               | RM-BT36         | Biposto tenor bridge bare     |
| 37               | RM-MB37         | Round Blk Plug 1"OD           |
| 37S              | RM-MB37S        | Round Blk Plug 7/8"OD         |
| 38               | RM-BT38         | Biposto saddle                |

## RM-BTABS-DH



RM-BTABS-DH

RANDALL MAY INTERNATIONAL

| Exploded View ID | RMI PART NUMBER | DESCRIPTION                                                                 |
|------------------|-----------------|-----------------------------------------------------------------------------|
| 1                | RM-ATQBB-DH1    | 5/8 x 12.75 Tube rail                                                       |
| 2L               | RM-BTDH2L       | Left Biposto tenor tube carrier arm                                         |
| 2R               | RM-BTDH2R       | Right Biposto tenor tube carrier arm                                        |
| 3L               | RM-ATQBB-DH3L   | N/A*                                                                        |
| 3R               | RM-ATQBB-DH3R   | N/A*                                                                        |
| 4LF              | RM-ATQBB-DH4LF  | N/A*                                                                        |
| 4RF              | RM-ATQBB-DH4RF  | N/A*                                                                        |
| 5                | RM-ATQBB-DH5    | Rotator Arm - Long (Standard)                                               |
| 6                | RM-ATQBB-DH6    | Bolt, wshr, shldr wshr & nut                                                |
| 7P               | RM-ATQBB-DH7P   | Keybolt and 2 washers                                                       |
| 8                | RM-ATQBB-DH8    | Bolt, washer, and nut                                                       |
| 9                | RM-ATQBB-DH9    | Bolt, Washer and Nut                                                        |
| 10               | RM-ATQBB-DH10   | Bolt, washer, nut                                                           |
| 11               | RM-ATQBB-DH11   | 1-3/4 hinge tube w/plug                                                     |
| 12               | RM-ATQBB-DH12   | tube cap                                                                    |
| 13               | RM-ATQBB-DH13   | Thumb Nut                                                                   |
| 14               | RM-ATQBB-DH14   | Socket Head Cap Screw                                                       |
| 15               | RM-ATQBB-DH15   | 1/4-20 x 1-1/4 screws and split washer                                      |
| 16               | RM-ATQBB-DH16   | 1/4-20x1-1/4 bolts, nuts, washers 2ea                                       |
| 17               | RM-ATQBB-DH17   | Anchor logo plate                                                           |
| 18               | RM-ATQBB-DH18   | Anchor logo plate brackets 2ea                                              |
| 19               | RM-ATQBB-DH19   | Tenor Arm Anchor w/pemnut                                                   |
|                  | RM-ATQBB-DH-DA* | L/R Drm2Arm Pivot Tube MntBrkt, INC 3L, 3R, 4L, 4R, 7P, 8, 9, 10, 11, & 12) |