

Exploded View ID	RMI PART NUMBER	DESCRIPTION
1M	RM-SHFOOT	SH Base Rubber Foot
2T	RM-SH2T	14-3/4 back leg RM-SHQ
3	RM-SH3	Base leg tube
4T	RM-SH4T	Main tube for SHQA
5	RM-SH5	SH base leg bracket
5N	RM-SH5N	SH Sliding Bracket
6	RM-SH6	SH double sliding bracket
6N	RM-SH6N	SHS lower fixed bracket
7	RM-SH7	SHS Bolt/nut set for fixed bracket
8	RM-SH8	Flat washer ea
9	RM-SH9	ATS leg brace for back leg
10	RM-SH10	Leg brace for base leg tube
1N	RM-SH11N	Middle sliding bracket
12	RM-SH12	ATS pivot
13	RM-SH13	Bolt and Nut for middle sliding bracket
14	RM-SH14	Leg Cap
15	RM-TBOLT3/8M	1/4-20 X 3/8" Metal T-Bolt
17	RM-SH17	SH Upper Pipe RM-SHS
18S	RM-TBOLT1/2M	1/4-20 X 1/2" TBolt Metal
18L	RM-TBOLT3/4M	Tbolt 1/4-20x3/4 Metal
19	RM-SH19	Set screw 1/4-20 x 1/4"
20	RM-SH20	SHS Head Screw
21	RM-SHQ21	Rubber bumper
22	RM-SH22	SH upper Pipe Cap
23	RM-SH23	SHS Bolt/nut set
25S	RM-SH25S	Bolt and washer
35N	RM-SHQ35N	Interior pipe for stabilizing bar
36N	RM-SHQ36N	Exterior pipe with 1" tube joint
37	RM-SHQ37	1" nose leg bracket
200	RM-SH200	Tube Joint SHII
200C	RM-SH200C	1-1/4 S/S BHCS
CLA	RM-SHBA-CLA	Red airlift lever w/fasteners
PQDL	RM-SHQA-PQDL	Tenor Drop&Lock Head
SS	RM-SHBA-SS	1/4-20x3/8 SS set screw